

Demagnetizer Spool EMD 1

The device removes the undesirable magnetism in sound heads and video heads and other iron parts.

Handling:

Bring the EMD 1 close to the part which is to be demagnetised, switch on, remove slowly from the part and in a distance of at least 30 cm switch off.

